

INSTRUCTIONS AND PARTS MANUAL

K-BUG 3000

K-BUG 3000
K-BUG 3002

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Model Number _____

Serial Number _____

Date of Purchase _____

Whenever you request replacement parts or information on this equipment, always supply the information you have recorded above.

LIT-KBUG-3000-IPM-1119

Bug-O Systems is committed to empowering our customers by providing operator controlled mechanized solutions for their welding, cutting and custom applications.



BUG-O SYSTEMS

A DIVISION OF WELD TOOLING CORPORATION



280 TECHNOLOGY DRIVE CANONSBURG, PENNSYLVANIA 15317-9564 USA
PHONE: 412-331-1776 <http://www.bugo.com> FAX: 412-331-0383


SAFETY

PROTECT YOURSELF AND OTHERS FROM SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



ELECTRIC SHOCK can kill.

- 1) The equipment is not waterproof. Using the unit in a wet environment may result in serious injury. Do not touch equipment when wet or standing in a wet location.
- 2) The unused connectors have power on them. Always keep the unused connectors covered with the supplied protective panels. Operation of the machine without the protective panels may result in injury.
- 3) Never open the equipment without first unplugging the power cord or serious injury may result.
- 4) Verify the customer-supplied power connections are made in accordance with all applicable local and national electrical safety codes. If none exist, use International Electric Code (IEC) 950.
- 5) Never remove or bypass the equipment power cord ground. Verify the equipment is grounded in accordance with all applicable local and national electrical safety codes. If none exist, use International Electric Code (IEC) 950.



READ INSTRUCTIONS.

Read the instruction manual before installing and using the equipment.



EQUIPMENT DAMAGE POSSIBLE.

- 1) Do not plug in the power cord without first verifying the equipment is OFF and the cord input voltage is the same as required by the machine or serious damage may result.
- 2) Always verify both the pinion and wheels are fully engaged before applying power or equipment damage may occur.
- 3) Do not leave the equipment unattended.
- 4) Remove from the work site and store in a safe location when not in use.



FALLING EQUIPMENT can cause serious personal injury and equipment damage.

Faulty or careless user installation is possible. As a result, never stand or walk underneath equipment.



MOVING PARTS can cause serious injury.

- 1) Never try to stop the pinion from moving except by removing power or by using the STOP control.
- 2) Do not remove any protective panels, covers or guards and operate equipment.

HIGH FREQUENCY WARNINGS

SPECIAL PRECAUTIONS ARE REQUIRED WHEN USING PLASMA, TIG OR ANY WELDING PROCESS THAT USES HIGH FREQUENCY TO STRIKE AN ARC.



WARNING: HIGH FREQUENCY CAN EFFECT MACHINE OPERATION AND THEREFORE, WELD QUALITY.

Read the precautions below before installing and using the equipment.

PRECAUTIONS:

- 1) Some plasma or welding cables are strong sources of high frequency interference. NEVER lay a plasma or welding cable across the controls of the machine.
- 2) Always physically separate the plasma or welding cable leads from the machine cables. For example, the plasma or welding cable leads should NEVER be bundled with a pendant cable or the machine power cord. Maximize the separation between any machine cables and the plasma or welding cables.
- 3) Strictly follow the grounding procedures specified for the plasma or welding unit. NOTE: Some plasma and welding units produce exceptionally large amounts of high frequency noise. They may require a grounding rod be driven into the earth within six feet (2 meters) of the plasma or welding unit to become compatible with an automatic cutting or welding process.
- 4) If the high frequency is produced using a spark gap, adjust the points so the gap is as small as possible. The larger the gap, the higher the voltage and the higher the interference.
- 5) Some plasma or welding units will inject high frequency interference into the AC power line. Use separate power line branches whenever possible to power the plasma or welding source and the machine. Do not plug them into the same outlet box.
- 6) High frequency noise may enter the machine through the plasma or welding supply remote contactor leads. Some plasma and welding sources can produce noise spikes of up to several thousand volts. These sources are not compatible with automated cutting and welding equipment. It is recommended that the remote contactor leads on these plasma or welding sources not be connected to the machine. An alternate solution is to purchase a separate remote contactor isolation box.

K-BUG 3000


K-BUG 3000, K-BUG 3002

INSTRUCTIONS AND PARTS MANUAL

TABLE OF CONTENTS

PAGE

| | |
|----|---|
| 5 |Introduction |
| 5 |Features |
| 5 |Technical Data |
| 5 |Dimensions |
| 6 |Illustration of Typical Applications |
| 6 |Stop Sensor Operation |
| 6 |Weave Patterns |
| 7 |User Interface - Control Panel |
| 8 |User Interface - Wireless Remote Control |
| 9 |Global Parameters |
| 9 |Converting Units |
| 10 |Installation and Operation |
| 10 |Cable Interconnect Diagram |
| 11 |Maintenance |
| 11 |Troubleshooting |
| 12 |Troubleshooting, Cont'd. |
| 13 |K-BUG 3000 Assembly View |
| 14 |K-BUG 3000 Wiring Diagram |
| 15 |KBUG-3010 Carriage Assembly / Exploded View |
| 16 |KBUG-3010 Carriage Assembly / Parts List |
| 17 |KBUG-3060 Control Panel / Exploded View / Parts List |
| 18 |KBUG-3070 Weaving Assembly / Exploded View / Parts List |
| 18 |KBUG-3080 Y-Slide Assembly / Exploded View / Parts List |
| 19 |KBUG-3100 Remote Control / Exploded View / Parts List |
| 19 |KBUG-3120 Torch Clamp Assembly / Exploded View / Parts List |
| 20 |KBUG-3130 Guide Roller Assembly / Exploded View / Parts List |
| 21 |SBG-450- _ - _ - _ Gun & Cable Assembly / Exploded View / Parts List |
| 22 |Accessories |
| 23 |Warranty |



INTRODUCTION

The K-BUG 3000 is a highly versatile fillet welder designed for all-position welding and equipped with a pendulum oscillator. The K-BUG 3000 drives on four rubber wheels and utilizes guide arms and a strong magnet in its base to adhere the machine to the work piece.

FEATURES

- Wireless Remote Control
- Digital displays for weld speed, dwell times, weave width and weave speed
- Independent left / right dwell times
- Five weave patterns
- Magnet release for easy positioning of carriage
- Electronics rated to 80 C (175 °F)
- Drive wheels rated to 400 °F (204 °C)

TECHNICAL DATA

Power Input

K-BUG 3000 120V / 50-60 Hz / 1 Phase

K-BUG 3002 240V / 50-60 Hz / 1 Phase

Weight 20 lb (9.2 kg)

Drive Motor 24 VDC, 12 W, 5000 RPM

Travel Speed 1.18 - 35 in/min (3.0 - 88 cm/min)

Torch Holder Fits barrels up to 0.75 in (19 mm)

Torch Angle Adjustable


Running Angle 90°

Y-Stroke 0 - 0.78 in (0 - 20 mm)

Weave Speed to 188 in/min (478 cm/min)*

Weave Width to 1.05 in (26.67 mm)*

Dwell Time 0 - 9.9 sec.



* When torch Pivot-to-Tip length is 6.0 in (152 mm), as shown at right.

Increasing the Pivot-to-Tip length will increase the maximum speed and the weave width.

DIMENSIONS



Bug-O Systems has a complete overview video of our K-BUG 3000. To watch this video, scan the qr code or visit: <https://www.youtube.com/watch?v=lx4LU2J48g8&t=94s>






ILLUSTRATION OF TYPICAL APPLICATIONS



Vertical Fillet Welding



Downhand Fillet Welding


STOP SENSOR OPERATION

The K-BUG 3000 is equipped with two (2) Stop Sensors. One sensor is placed on the right side of the carriage, the other is placed on the left. The Stop Sensors are normally open switches that engage or close when depressed. If a sensor is tripped during welding, carriage travel will immediately stop and Crater Fill will be performed. Remove the obstacle to reset the Stop Sensor. Press Cycle Start Button to begin weld cycle again.

WEAVE PATTERNS

| Symbol | Number | Name | Description |
|--------|--------|---------------|---|
| — | 1 | No Weave | Performs straight-line (linear) weld. |
| ∩ | 2 | Run | Tractor moves continuously -- during weave and dwell. |
| ∩ | 3 | Stop on Dwell | Tractor moves during weave and pauses on dwell. |
| ∩ | 4 | Step | Tractor pauses during the weave and travels during the dwell. |
| ∩ | 5 | Saw Tooth | Tractor pauses while weave moves <i>away</i> from tractor, then tractor moves while weave moves <i>toward</i> the tractor. Tractor pauses on dwell. |

USER INTERFACE - CONTROL PANEL



- Cycle Start Button** - Push button to initiate weld cycle. Weld contact will close if the Weld Switch is set to Auto and carriage will travel in the direction selected by the Travel Direction Switch.
- Cycle Stop Button** - Push button to stop welding cycle.
- Travel Speed Adjustment Knob** - Rotate knob to adjust carriage travel speed. Turning clockwise (right) will INCREASE speed.
- Travel Direction Switch** - Set switch to determine direction of carriage travel. Travel direction should be set *before* carriage travel is started.
- Weld Auto / Off Switch** - When switched to AUTO, weld contact will close with cycle start.
- Weave Speed Adjustment Knob** - Increase weaving speed by turning knob clockwise; decrease by turning counterclockwise.
- Weave Width Adjustment Knob** - Increase the weave width by turning the knob clockwise; decrease by turning counterclockwise.
- Dwell Time Adjustment** - Increase or decrease dwell time by turning the adjustment knob. The outer knob controls the left dwell; the inner knob controls the right dwell. The range for these settings is 0 - 9.9 sec.
- Steering Knob** - Turn knob clockwise to shift weave center to the right. Turning the knob counterclockwise will cause a shift to the left.
- Weave Select Button** - Use this button to select the weave type to be performed. Push the Weave Select Button (10) to select the desired weave number is displayed.

Displays - Digitally display real-time values during welding. Acceptable range, default value and units for each display are listed in the table, below. Also used when setting Parameters and enabling the remote.

| Display | Description | Range | Default | Unit |
|---------|----------------|------------------------|---------|--------------------|
| A | Travel Speed | 0 - 85.0 (0 - 33.5) | 50.0 | cm/min (in/min) |
| B | Weave Selector | 1 - 5 | 5 | |
| C | Left Dwell | 0.0 - 9.9 | 3 | sec |
| D | Right Dwell | 0.0 - 9.9 | 3 | sec |
| E | Weaving Width | 0 - 99 | 30 | % |
| F | Weaving Speed | 0 - 99 | 30 | % |

USER INTERFACE - WIRELESS REMOTE CONTROL

The Digital Weaver includes a wireless remote that can be used to control the machine. Magnets in the back of the remote allow for easy storage on the machine. The remote has a range of 33 ft (10 m). Each remote communicates at a unique frequency, allowing multiple machines to operate in close proximity without interference.

The control functions of the remote differ from the control panel as follows:




Figure 8: Remote Control Overview

ENABLING THE REMOTE CONTROL

The remote is factory enabled. However, following certain maintenance activities, such as replacing the battery or Main PCB, it will be necessary to enable the remote or establish communication between the remote and the machine.

1. While pressing the orange Stop button (on the machine control panel), connect the machine to power.
2. Release the orange Stop button.
3. While pressing the Stop button on the REMOTE, turn the remote ON. Continue to hold the Stop button for 3 - 5 seconds.
4. Release the Stop button on the REMOTE. The machine should reset and return to normal operating conditions.
5. Press the Start button on the REMOTE to confirm it was set.
6. If the machine DOES NOT START, repeat steps 1-5.

NOTE: Once communication has been established between a remote and a machine, that remote will only work with that machine. It cannot be used to control any other K-BUG device.

GLOBAL PARAMETERS

1. While holding down the Start button, plug the machine into an AC power source of appropriate voltage.
2. The active parameter will be displayed in the Left Dwell display. The current setting for the active parameter will be displayed in the Travel Speed display.
3. To adjust the active parameter, turn the Travel Speed Adjustment knob. Turning to the right, or clockwise, will increase the value; counterclockwise will decrease the value.
4. Press and release the Cycle Start button to scroll through the parameters.
5. When finished setting (all) values, press the Cycle Stop button and unplug the machine.

| Display | Description | Range | Default | Unit |
|---------|--------------------------------|------------|---------|--------------------------|
| n.0 | Puddle Build-up | 0.0 - 9.9 | 1 | sec |
| n.1 | Crater Fill | 0.0 - 9.9 | 1 | sec |
| n.2 | Weave speed with Center Return | 0 - 99 | 99 | sec |
| n.3 | Maximum Weave Width | 0 - 90 | 5 | Degree |
| n.4 | Center Move Width | -- | 360 | Degree |
| n.5 | Center Move Length | 1 - 60 | 2 | Pulse |
| n.6 | Diff Value of travelling speed | 1 - 20 | 10 | |
| n.7 | Signed data auto diff speed | 1 - 7 | 7 | |
| n.8 | Motor emcy Auto Stop Time | 0.0 - 9.9 | 3 | sec |
| n.9 | Travel Motor Reduce Ratio | 20 - 200 | 40 | |
| n.a | Weaving Motor Ratio | 20 - 200 | 100 | |
| n.b | Travel Wheel Diameter | 0.0 - 99.9 | 22.5 | mm |
| n.c | Demonstration Mode | On / Off | Off | |
| n.d | Operating Units | U1 / U2 | U2 | U1 (cm/min), U2 (in/min) |

CONVERTING UNITS


By default, the K-BUG 3000 will be factory set to operate in English units (in/min). If it is necessary to change units, follow the steps for checking Global Parameters, above. Use the Cycle Start button until "5" is shown on the Display. Turn the Travel Speed Adjustment knob right or left to select the desired Units. Choose "U1" for Metric (cm/min) or "U2" for English (in/min).

INSTALLATION AND OPERATION

Cable Connections

- Clamp torch into the Torch Clamp Assembly
 - Connect Weld Contactor lead from machine to contact circuit of feeder
 - Connect power input cable to proper electric source
 - Make all connections between power source and wire feeder
- CAUTION:** Carefully route power cable as it may become entangled during operation, resulting in damage to people or equipment.
- Set the Carriage so the torch is at the weld starting point
 - Adjust the target angle and position of the Torch, as needed
 - Set welding parameters as needed - Weave Width, Dwell times, Weave type
 - Verify adequate Shielding Gas Supply
 - Set weld enable switch to ON
 - Start Welding - Toggle Welding Switch to AUTO, verify desired travel direction is set and travel speed is > 0 in/min and press Cycle Start Button
 - Press Cycle Stop Button when welding is complete

CABLE INTERCONNECT DIAGRAM



MAINTENANCE

The Bug-O K-BUG 3000 carriage should be periodically checked and cleaned to maximize service life.

Before use:

Check all screws in the torch clamp and guide rollers. Tighten as needed. Loose fasteners may cause uneven travel or inconsistent weld quality.

During use:

Monitor wheels, motor and welding torch for abnormal noise or overheating.

After each use:

1. Clean control panel to remove dust and other debris.
2. Inspect carriage base, wheels, guide rollers, slide adjustment, magnets and torch for weld spatter or other debris. Clean as needed.
3. Inspect power cable and torch cable for cracked, cut or damaged insulation. Replace as needed.
4. Inspect connectors for damaged pins or loose connections. Replace as needed.



TROUBLESHOOTING

| Symptom | Cause | Repair |
|---|---|--|
| Control panel Display is not LIT | Disconnected Control Cable | Verify control cable is properly connected to machine |
| | Faulty Control Cable | Replace Cable |
| | Control Box Fuse Tripped or Disconnected | Replace fuse. If problem persists, contact service rep. |
| No Arc when Welding Auto/Off Switch turned to AUTO (and Cycle Start is pressed) | Weld Auto/Off Switch set to OFF | Turn Weld Auto/Off Switch to AUTO |
| | Loose contact of Welding Leads | Check ground connections. Verify good contact on clean, unpainted surface. |
| | Bad or incorrectly wired Welding Auto/Off Switch | Check Wiring. Replace Switch, if needed |
| | Stop Sensor Engaged | Disengage Stop Sensor |
| Carriage does not travel when Cycle Start Button is pushed | Failed drive component | Check Motor, Drive Chain and Gearbox. Replace as needed |
| | Faulty or incorrectly wired Cycle Start Button | Check Wiring. Replace button, if needed. |
| | Faulty MAIN PCB | Replace MAIN PCB |
| | Stop Sensor Engaged | Disengage Stop Sensor |
| Torch targets wrong position | Loose fastener on Torch Clamp | Check and tighten screws, replace if needed. |
| Slide is hard to adjust | Dust or other debris on slide parts | Clean slide parts. Lubricate with light oil |
| Carriage stops during automatic welding | Stop sensor engaged | Disengage Stop Sensor |
| | Power Cable disconnected | Reroute and reconnect Power Cable |
| Arc continues after Welding Auto/Off Switch is set to OFF | The Welding Auto/Off Switch is still set to Auto | Turn Weld Auto/Off Switch to OFF |
| | Faulty or incorrectly wired Welding Auto/Off Switch | Check Wiring. Replace Switch, if needed. |


TROUBLESHOOTING, CONT'D.

K-BUG ERROR LIST

| NO. | SYMPTOM | CAUSE | SOLUTION |
|------|-----------------|--|--|
| E-03 | Motion Stop | Main PCB EET ROM Error | Main PCB Replacement |
| E-05 | Travelling Stop | Auto-Stop Travelling Motor may be overloaded / shorted | Push and release Stop Button IF UNRESOLVED: 1. Check for loose wiring connection at drive motor and weave motor if equipped (see below). 2. Replace motor or motor reducer 3. Replace main PCB |



K-BUG 3000 ASSEMBLY VIEW




| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|---|
| 1 | 1 | KBUG-3010 | Carriage Assembly |
| 2 | 1 | KBUG-3060 | Control Tower Assembly |
| 3 | 1 | KBUG-3070 | Weaver Assembly |
| 4 | 1 | KBUG-3078 | Weaving Fixed Bracket |
| 5 | 1 | KBUG-3077 | Slide Fixed Plate |
| 6 | 1 | KBUG-3080 | Y-Slide Assembly |
| 7 | 1 | KBUG-3120 | Torch Clamp Assembly |
| 8 | 1 | KBUG-3130 | Guide Arms Assembly |
| 9 | 1 | KBUG-3100 | Wireless Remote Controller |
| 10 | 4 | MET-0577-SS | Soc Hd Cap Scr M4 x 16 |
| 11 | 4 | MET-0553-SS | Soc Hd Cap Scr M4 x 10 |
| * | 1 | KBUG-2274-15** | Power Cable, 120 VAC, 15' (4.5 m) |
| * | 1 | KBUG-3079 | Weaving Cable Assembly |
| * | 1 | KBUG-3092** | Charging Unit 120 VAC / 50-60 Hz / 1 Ph |


* Not Shown

** Note: For K-BUG 3002 (240 VAC model), Power Cable is KBUG-2272-15 and the Remote Charger is KBUG-3093.

K-BUG 3000 WIRING DIAGRAM




KBUG-3010 CARRIAGE ASSEMBLY / EXPLODED VIEW



KBUG-3010 CARRIAGE ASSEMBLY / PARTS LIST


| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|------------------|------------------------|
| 1 | 1 | KBUG-3011 | Body |
| 2 | 1 | KBUG-3012 | Magnet |
| 3 | 1 | KBUG-3013 | Lever Cover |
| 4 | 1 | KBUG-3014 | Grip Cover |
| 5 | 2 | KBUG-3015 | Sensor Cover |
| 6 | 1 | KBUG-3016 | Motor Joint Case |
| 7 | 1 | KBUG-3017 | Small Magnet |
| 8 | 1 | KBUG-3018 | Lever Shaft |
| 9 | 1 | KBUG-3019 | Magnet Plate |
| 10 | 1 | KBUG-3021 | Lever Housing Plate |
| 11 | 1 | KBUG-3056 | Magnet Bracket |
| 12 | 2 | KBUG-3022 | Guide Plate |
| 13 | 1 | KBUG-3023 | Lever Plate |
| 14 | 1 | KBUG-3024 | Lever Bushing |
| 15 | 1 | KBUG-3025 | Grip Bracket |
| 16 | 1 | KBUG-3026 | Tension Bushing |
| 17 | 1 | KBUG-3027 | Tension Shaft |
| 18 | 1 | KBUG-3028 | Slide Fixed Bracket |
| 19 | 4 | KBUG-3029 | Shaft Bushing |
| 20 | 1 | KBUG-3031 | Grip |
| 21 | 1 | KBUG-3032 | Lever Housing-1 |
| 22 | 1 | KBUG-3033 | Lever Housing-2 |
| 23 | 1 | KBUG-3034 | Gear Head |
| 24 | 1 | KBUG-3035 | Panel Cover |
| 25 | 1 | KBUG-3036 | Spatter Cover |
| 26 | 1 | KBUG-3037 | Motor Cover |
| 27 | 1 | KBUG-3038 | DC Brushless Motor |
| 28 | 2 | KBUG-3039 | Spatter Cover Bolt |
| 29 | 1 | KBUG-3041 | Bottom Cover |
| 30 | 4 | KBUG-3042 | Snap Ring |
| 31 | 4 | KBUG-1036 | Wheel |
| 32 | 4 | KBUG-3044 | Wheel Cover |
| 33 | 2 | KBUG-3045 | Wheel Shaft |
| 34 | 2 | KBUG-3046 | Chain Sprocket |
| 35 | 2 | KBUG-3047 | Sensor Bushing |
| 36 | 4 | KBUG-3048 | Shaft Bearing |
| 37 | 1 | KBUG-3049 | Chain |
| 38 | 2 | KBUG-3051 | Stop Sensor |
| 39 | 1 | KBUG-3052 | Shaft Gear |
| 40 | 1 | KBUG-3053 | Center Gear |
| 41 | 1 | KBUG-3054 | Gear Bushing |
| 42 | 1 | KBUG-3055 | Gear Bearing |
| 43 | 2 | N60799-105-14-02 | Flt Hd Scr M5 x 15 |
| 44 | 2 | MET-0577-SS | Soc Hd Cap Scr M4 x 13 |
| 45 | 6 | N18230-205-10-00 | Soc Hd Cap Scr M5 x 10 |
| 46 | 1 | MET-0570 | Soc Hd Cap Scr M6 x 30 |
| 47 | 4 | N60799-105-12-02 | Flt Hd Soc Scr M5 x 12 |
| 48 | 2 | MET-0553-SS | Soc Hd Cap Scr M4 x 10 |
| 49 | 8 | N60091-204-50-00 | Flt Hd Scr M4 x 5 |
| 50 | 2 | N18230-205-30-00 | Soc Hd Cap Scr M5 x 30 |
| 51 | 2 | MET-1370-SS | M6 Hex Nut |
| 52 | 2 | MET-0953-SS | Flt Hd Soc Scr M4 x 8 |
| 53 | 1 | N18230-206-14-00 | Soc Hd Cap Scr M6 x 14 |
| 54 | 2 | MET-0953-SS | Flt Hd Soc Scr M4 x 9 |

KBUG-3060 CONTROL TOWER ASSEMBLY / EXPLODED VIEW / PARTS LIST




| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|------------------------------|
| 1 | 1 | KBUG-3061 | Panel |
| 2 | 1 | KBUG-3062 | Legend Plate |
| 3 | 1 | KBUG-3063 | Main PCB |
| 4 | 1 | KBUG-3064 | Power PCB |
| 5 | 2 | KBUG-1124 | Push Button Covers |
| 6 | 2 | KBUG-3116 | Weaving Connector |
| 7 | 1 | KBUG-1133 | Torch Connector |
| 8 | 2 | KBUG-1132 | Power Connector |
| 9 | 1 | KBUG-1131 | Fuse |
| 10 | 2 | KBUG-3112 | Push Button |
| 11 | 2 | KBUG-1122 | Toggle Switch Cover |
| 12 | 1 | KBUG-1128 | Push Button Cover, Black |
| 13 | 1 | KBUG-1127 | Push Button Cover, Orange |
| 14 | 6 | KBUG-1129 | Volume Knob |
| 15 | 2 | KBUG-3114 | Toggle Switch |
| 16 | 1 | KBUG-3166 | Panel Bracket |
| 17 | 1 | KBUG-3068 | Panel Plate |
| 18 | 4 | MET-0143-SS | Pan Hd Phil Scr M3 x 10 |
| 19 | 6 | MET-0053 | Pan Hd Phil Scr M4 x .7 x 10 |
| 20 | 4 | MET-0141-SS | Pan Hd Phil Scr M3 x 6 |
| 21 | 9 | MET-0943 | Flt Hd Soc M3 x 10 |

KBUG-3070 WEAVING ASSEMBLY / EXPLODED VIEW / PARTS LIST




| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|-----------------------|
| 1 | 1 | KBUG-3071 | DC Brushless Motor |
| 2 | 1 | KBUG-3072 | R/W Geared Motor |
| 3 | 1 | KBUG-3073 | Motor Case |
| 4 | 1 | KBUG-3074 | Connector BRK |
| 5 | 1 | KBUG-3075 | Weaving Spatter Cover |
| 6 | 1 | KBUG-3076 | Bushing |
| 7 | 1 | KBUG-3116 | Weaving Connector |

KBUG-3080 Y-SLIDE ASSEMBLY / EXPLODED VIEW / PARTS LIST



| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|--------------------------|
| 1 | 1 | KBUG-3081 | Horizontal Slide Housing |
| 2 | 2 | KBUG-3082 | Slide Bar |
| 3 | 1 | KBUG-3083 | Slide Bolt |
| 4 | 1 | KBUG-3084 | Slide Bolt Cover |
| 5 | 1 | KBUG-3085 | Slide Cover |
| 6 | 1 | KBUG-3086 | Slide Unit Bracket (U) |
| 7 | 1 | KBUG-3087 | Slide Unit Bracket (D) |
| 8 | 1 | KBUG-3089 | Slide Block (L) |
| 9 | 1 | KBUG-3091 | Knob |
| 10 | 8 | MET-0553-SS | Soc Hd Cap Scr M4 x 10 |
| 11 | 4 | MET-0552-SS | Soc Hd Cap Scr M4 x 8 |

KBUG-3100 REMOTE CONTROL / EXPLODED VIEW / PARTS LIST




| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|------------------------------------|
| 1 | 1 | KBUG-3101 | Panel Case |
| 2 | 1 | KBUG-3102 | Remote Name Panel & Legend Sticker |
| 3 | 1 | KBUG-3103 | Main PCB |
| 4 | 1 | KBUG-3104 | Battery |
| 5 | 1 | KBUG-3105 | Switch |
| 6 | 2 | KBUG-3106 | Rubber Magnet |
| * | 1 | KBUG-3092** | Charging Unit 120 VAC |

* Not Shown


** Note: For K-BUG 3002 (240 VAC model) the Remote Charger is KBUG-3093.

KBUG-3120 TORCH CLAMP ASSEMBLY / EXPLODED VIEW / PARTS LIST



| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|--------------------|
| 1 | 1 | KBUG-3121 | Torch Clamp (L) |
| 2 | 1 | KBUG-1111 | Torch Clamp (U) |
| 3 | 1 | KBUG-1113 | Clamp Fixed Knob |
| 4 | 1 | KBUG-1112 | Clamp Fixed Bolt |


KBUG-3130 GUIDE ROLLER ASSEMBLY / EXPLODED VIEW / PARTS LIST



| <u>ITEM</u> | <u>QTY</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> |
|-------------|------------|-----------------|-------------------------------|
| 1 | 1 | KBUG-3131 | Guide Arm (L) |
| 2 | 2 | KBUG-1063 | Guide Roller Cover |
| 3 | 2 | KBUG-3132 | Guide Roller Bracket |
| 4 | 2 | KBUG-3162 | Guide Roller |
| 5 | 2 | KBUG-1061 | Guide Roller Bushing |
| 6 | 1 | KBUG-3133 | Guide Arm (R) |
| 7 | 2 | 100-0378 | Acorn Nut M6-1.0 |
| 8 | 2 | 100-0383 | Flt Hd Phil Scr M6-1.0 x 25mm |

SBG-450- - - GUN & CABLE ASSEMBLY / EXPLODED VIEW / PARTS LIST

Whip Length: 15 (15 ft / 4.6 m) or 25 (25 ft / 7.6 m)
 Wire Size: .035, .040, .045, .052, .116, .564
 Connector Type: E (Euro), L (Lincoln 3/4"), M (Miller), T (Lincoln, small)




| PARTS LIST | | | | WIRE SIZE | | | | | |
|------------|-----|--------------|-------------------------------|-----------------|---------------|---------------|---------------|---------------|---------------|
| ITEM | QTY | PART NO. | DESCRIPTION | .035 (.9 mm) | .040 (1.0) | .045 (1.2) | .052 (1.4) | 1/16 (1.6) | 5/64 (2.0) |
| 1 | 1 | BUG-3159-35 | 16S-35 (.9 mm) Contact Tip | X | | | | | |
| 1 | 1 | BUG-3159-45 | 16S-45 (1.2 mm) Contact Tip | | | X | | | |
| 1 | 1 | BUG-3159-52 | 16S-52 (1.4 mm) Contact Tip | | | | X | | |
| 1 | 1 | BUG-3159-116 | 16S-116 (1.6 mm) Contact Tip | | | | | X | |
| 1 | 1 | BUG-3159-564 | 16S-564 (2.0 mm) Contact Tip | | | | | | X |
| 1 | 1 | PWS-4436-1.0 | 16S-40 (1.0 mm) Contact Tip | | X | | | | |
| 2 | 1 | PWS-4447 | 27S62 H.D. Nozzle 5/8" | X | X | X | X | X | X |
| 3 | 1 | PWS-4449 | PX57HD Gas Diffuser | X | X | X | X | X | X |
| 4 | 1 | CWO-8017 | Case w/ Binder Screws (Front) | X | X | X | X | X | X |
| 5 | 1 | PWS-4411 | Case w/ Binder Screws (Back) | X | X | X | X | X | X |
| 6 | 1 | STW-3044 | 450 Amp Cable | X | X | X | X | X | X |
| 7 | 1 | R174-T | Connector, Small Lincoln | | | | | | |
| 7 | 1 | R174-L | Connector, 3/4" Lincoln | | | | | | |
| 7 | 1 | R174-M | Connector, Miller | | | | | | |
| 7 | 1 | R174-X | Connector, Euro | | | | | | |
| 8 | 1 | CWO-8009 | 44-3545-15 Cable Liner | X | X | X | | | |
| 8 | 1 | CWO-8011 | 44-116-15 Cable Liner | | | | X | X | |
| 8 | 1 | CWO-8012 | 44-564-15 Cable Liner | | | | | | X |
| ** | 1 | SBG-1004 | Gas Hose Assembly | X | X | X | X | X | X |
| ** | 2 | SBG-1005 | Gas Hose Clamps | X | X | X | X | X | X |

** Not shown. Required only with standard Lincoln guns (SBG-450-L).

ACCESSORIES


KBUG-1067 Magwheel Add-On Kit

Magnetic guide wheels available for curved or irregular seams.




KBUG-3005-BW Butt Weld Kit

Adjustable slide arm positions torch farther from the carriage body, allowing the User greater flexibility welding fillet or butt joints. Second slide allows fine-tune height adjustment of torch.




KBUG-1290 Cable Anchor

The cable anchor acts as a strain relief to keep the supply cable from dragging the torch out of position.



KBUG-1170 Long Arm Assembly

Convenient torch holder assembly to relocate torch away from the machine to reduce heat affects. This can be used for welding applications other than downhand.



WARRANTY

LIMITED WARRANTY

MODEL _____
SERIAL NO. _____
DATE PURCHASED: _____

FOR A PERIOD OF TWELVE (12) MONTHS FROM DELIVERY, BUG-O SYSTEMS WARRANTS TO THE ORIGINAL PURCHASER (DOES NOT INCLUDE AUTHORIZED DISTRIBUTORS), THAT A NEW MACHINE IS FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP AND AGREES TO REPAIR OR REPLACE, AT ITS OPTION, ANY DEFECTIVE PARTS OR MACHINE. THIS WARRANTY DOES NOT APPLY TO MACHINES, WHICH AFTER OUR INSPECTION, ARE DETERMINED TO HAVE BEEN DAMAGED DUE TO NEGLIGENCE, ABUSE, OVERLOADING, ACCIDENT OR IMPROPER USAGE. ALL SHIPPING AND HANDLING CHARGES WILL BE PAID BY CUSTOMER.

BUG-O SYSTEMS MAKES NO WARRANTY OF MERCHANTABILITY AND MAKES NO OTHER WARRANTY, EXPRESSED OR IMPLIED, BEYOND THE WARRANTY EXPRESSLY SET FORTH ABOVE. BUYER'S REMEDY FOR BREACH OF WARRANTY, HEREUNDER, SHALL BE LIMITED TO REPAIR OR REPLACEMENT OF NON-CONFORMING PARTS AND MACHINES. UNDER NO CIRCUMSTANCES SHALL CONSEQUENTIAL DAMAGES BE RECOVERABLE.

HOW TO OBTAIN SERVICE:

IF YOU THINK THIS MACHINE IS NOT OPERATING PROPERLY, RE-READ THE INSTRUCTION MANUAL CAREFULLY, THEN CALL YOUR AUTHORIZED BUG-O DEALER/DISTRIBUTOR. IF HE CANNOT GIVE YOU THE NECESSARY SERVICE, WRITE OR PHONE US TO TELL US EXACTLY WHAT DIFFICULTY YOU HAVE EXPERIENCED. BE SURE TO MENTION THE MODEL AND SERIAL NUMBERS.